

T.I. no.: 2017 - 15 Updated: -	Topic: SC Soul USB connection
---	--------------------------------------

Date: 24.08.2017
Affected machines: SC Soul
From serial number: 1722.../
As of date: CW22

Priority
High
Medium
X Low

Need for action
As soon as possible
On next visit to the machine
X FYI only

NEW USB WIRING

Up to now, the USB port has always been connected via the interface board (079073). In certain cases, the USB stick is not detected. Due to this error, the USB port will be connected directly to the touch panel starting in CW 22.

This change should be made in the field for machines with this problem. To do so, observe the following steps:

- ▶ Remove the machine housing.
- ▶ Carefully remove the cable (079115) led to the connector strip from the display.
- ▶ Pull the cable (079439) out of the connector strip and connect it to the USB port of the display. The cable must be laid in the same path as the removed cable and fixed with cable ties.
- ▶ Check the function of the USB connection with the USB stick.



(EN) This page is intentionally left blank.

(DE) Diese Seite wurde absichtlich frei gelassen.

(FR) Cette page est laissée vide intentionnellement.

(ES) Esta página se dejado en blanco intencionalmente.