

T.I. no.: 2024-05 Updated: -	Topic: Software V5.24.7 Release Notes
--	--

Date: 15.04.2024
Affected machines: SOUL, SKYE
From serial number: -
Start date: immediately

Priority and need for action	
<input type="checkbox"/>	High: as soon as possible
<input checked="" type="checkbox"/>	Medium: on next visit to the machine
<input type="checkbox"/>	Low: FYI only

INFORMATION ON SOFTWARE UPDATE

New functions have been added and errors eliminated with software update V5.24.7. The platform software optimises and replaces software version V5.18.5.

Overview of the most important new functions

- New parameters have been integrated in the **Cleaning** menu with the **Steam wand rinsing** (Clean & Purge) function.
- Dynamic language selection is possible.
- Telemetry is displayed as *active* when mobile payment or second screen is active.
- Remaining **ProCare** cleaning product (alkaline/acidic) is displayed as a per cent value.
- Descaling with **ProCare** is included in the remaining cleaning product calculation.
- **ProCare** is displayed correctly for the commissioning assistant.
- Cleaning bags are no longer refilled during **ProCare** cleaning when a limit value is undercut.
- New **ProCare** animations with TwinMilk option have been added.
- If more than two recipes are configured, an additional menu bar becomes visible on the right in Staff mode and in Frequent user mode.

Corrections/Troubleshooting

- Unfounded flow meter errors have been fixed.
- Error resulting in machine inoperability due to the **Payment retry** function has been fixed.
- The button for cancelling a beverage is no longer greyed out after actuation.
- SKYE with internal tank without milk system with steam wand can no longer be configured.
- Syrup quantities are now transmitted to telemetry in millilitres instead of microlitres.
- **Plug&Clean** before the cleaning step is displayed correctly when **Switch off after cleaning** is activated.
- Incorrect text display when replacing the ProCare BLUE / ProCare RED cleaning bag has been fixed.
- Error resulting in the MR node being displayed on the SKYE in the component test although it is not present has been fixed.